



KONICA MINOLTA

Account Tracking and User Authentication

How To Guide

For Konica Minolta bizhub Devices

For the bizhub Colour Series



Table of Contents

When to use Account Tracking and/or User Authentication.....	3
Account Track / User Authentication Common Settings	
Deleting Other User's Jobs	4
Log Off Confirmation Screen	4
Turning on Account Tracking from the Device Panel.....	5
Turning on User Authentication with Public User Mode from the Device Panel.....	6
Turning on Account Tracking using the Web Connection	7
Turning on User Authentication with Public User Mode using the Web Connection	8
Adding, Editing, and Deleting User Accounts from the Device Panel	9
Adding, Editing, and Deleting User Accounts using the Web Connection	10
Entering User Codes into Printer Drivers (PC's).....	11
Printing with Pop Up Authentication (PC's).....	11
Entering User Codes into Printer Drivers (Mac's)	12
Printing with Pop Up Authentication (Mac's).....	12
Generating Reports for Account Tracking and User Authentication from the Device Panel	13
Generating Reports for Account Tracking and user Authentication using the Web Connection	14
Resetting Counters	15

When to use Account Tracking

Account tracking can be used when everyone must enter a code to use the device to keep track of copying and printing. Codes can be assigned to each individual, or by department, or by client files, etc. When a code must be entered to track all copying and printing, Account Tracking is the easiest to use because it can be set to require only a password to authenticate at the device for copying or at the printer driver for printing. This saves users time. Passwords should therefore be kept numeric to make authenticating as quick and easy as possible, though alphanumeric passwords are also possible.

When to use User Authentication

User Authentication is the only feature that will allow the use of the biometric scanner or card reader to authenticate. User Authentication can also be used on Colour devices when clients only wish to manage *colour* copying and printing, but allow black & white copying and printing without tracking the number of prints, and requiring authentication only to copy or print in colour (*Public User mode*).

**** Please Note:** If you currently have to enter a code at the device to make a copy, then Account Tracking or User Authentication is already turned on. You can then skip the section on Turning On Account Track / User Authentication and go straight to the section on Adding Editing Or Deleting Accounts starting on page 9.

Account Track/User Authentication Common Settings

Deleting Other Users Jobs

When any form of authentication is turned on the default security setting is to prohibit users from deleting anyone else's jobs. The only way to delete jobs in the queue would be to have the user who sent the jobs to the device log in, then delete the jobs from the queue. To change the default setting to allow any user to delete jobs from the queue follow these steps after you have turned on your authentication settings:


1. At the device panel select the Menu button.
2. On the screen select Utility.
3. Select Administrator Settings and enter the admin password when prompted.
4. Select System Settings.
5. Select Restrict User Access.
6. Select Restrict Access to Job Settings.
7. Select Delete Other User Jobs and select Allow. Select OK to save the settings.



Logout Confirmation Screen


When any form of authentication is turned on the default setting is to ask users to confirm if they want to log out when they select the Access key once they are finished their tasks. You can turn off this confirmation screen to make it quicker for users to log out of their account when finished at the device. Follow the steps below to turn off the confirmation screen from the device panel. You can also turn off the confirmation screen using the web connection (see instructions at the end of pages 7 or 8).

1. At the device panel select the Menu button.
2. On the screen select Utility.
3. Select Administrator Settings and enter the admin password when prompted.
4. Select User Authentication/Account Track.
5. Select User/Account Common Settings
6. Select Logout Confirmation Screen Display Setting and select OFF. Select OK to save the settings.




Turning On Account Tracking From the Device Panel

1. Select the Menu button.
2. On the screen touch Utility.
3. Select Administrator Settings. (See your administrator for the device's admin password).
4. Select option #4: User Authentication/ Account Track.
5. Select option #1: General Settings
6. Select the Account Tracking feature and turn it ON.
7. Select Authentication Method and choose Password Only.
8. Press OK and confirm to proceed when prompted.
9. Go to page 9 of this guide for instructions on adding new accounts from the Device Panel.
10. Enter the codes into the print drivers. Printing will not be allowed without this. (See instructions starting on page 11).



Turning on User Authentication with Public User Mode from the Device Panel


1. Select the Menu button.
2. On the screen select Utility.
3. Select Administrator Settings. (See your administrator for the device's admin password).
4. Select option #4: User Authentication/Account Track.
5. Select option #1: General Settings
6. Select User Authentication and select ON (MFP).
7. Select Public User Access and choose the 3rd option ON (Without Login).
8. Select OK and confirm to proceed when prompted.
9. From the User Authentication/Account Track menu select option #2 User Authentication Settings.
10. Select User Registration.
11. Screen 1 of 50 of accounts will be displayed. Scroll **up** to the last page to find the Public User account. Select it and touch Edit.
12. Select Output Permissions and choose Restrict for Colour Output. Press OK. This will require users to enter a password in order to copy or print in colour, but allow black & white copying and printing with no restrictions.
13. Go to page 9 of this guide for instructions on adding new user accounts from the Device Panel.
14. Enter the codes into the print drivers. Printing will not be allowed without this. (See instructions starting on page 11).




Turning On Account Tracking Using the Web Connection



1. Type in the IP address of your device into the address bar of your web browser.
2. If no authentication is turned on you will go straight into Public User mode. You need to login as an Administrator in order to access the Authentication settings. To get to the login screen click on **To Login Screen** in the top right corner of the screen and click OK.
3. Once at the login screen select Administrator and click Login. You will then be prompted to enter the device's administrator password (See your administrator for the password).
4. Click on User Authentication / Account Track
5. Select ON for Account Track and Password Only for Account Track Input Method. Click OK and confirm to proceed when prompted.
6. Click on User/Account Common Setting. Change Logout Confirmation Display Setting to Off. Click OK to save the setting.
7. Go to page 10 of this guide for instructions on how to add new accounts using the Web Connection.
8. Enter the codes into the print drivers. Printing will not be allowed without this. (See instructions starting on page 11).

General Settings	
User Authentication	OFF
Overwrite User Info	Restrict
Default Authentication Method	ON (External Server)
Public User Access	Restrict
Ticket Hold Time Setting (Active Directory)	500 Minute (1-600)
Account Track	ON
Account Track Input Method	Password Only
Synchronize User Authentication & Account Track	Synchronize
Number of Counters Assigned for Users	(1-999)
When Number of Jobs Reach Maximum	Skip Job



User/Account Common Setting	
Single Color > 2 Color Output Management	Color
Logout Confirmation Display Setting	OFF

Turning on User Authentication with Public User Mode Using the Web Connection

1. Type in the IP address of your device into the address bar of your web browser.
2. If no authentication is turned on you will go straight into Public User mode. You need to login as an Administrator in order to access the Authentication settings. To get to the login screen click on **To Login Screen** in the top right corner of the screen and click OK.
3. Once on the login screen select Administrator and click Login. (See your administrator for the device's admin password).
4. Select User Auth / Account Track.
5. Select ON (MFP) for User Authentication and ON (Without Login) for Public User Access. Click OK and confirm to proceed when prompted.
6. Select User Authentication Settings and then Public User.
7. Select Restrict for Colour Output Permission (Print). NOTE: Colour Output Permission (TX) refers to colour scanning.
8. Click OK at the bottom of the screen.
9. Click on User/Account Common Settings. Change Logout Confirmation Display Setting to Off. Click OK to save the setting.
10. Enter the codes into the print drivers. Printing will not be allowed without this. (See instructions starting on page 11).



Language: OS Language (OS Language)

Login: Public User Administrator

View Mode: Flash HTML

User Assist: Display dialog box in case of warning

KONICA MINOLTA Administrator Logout

PAGE SCOPE Web Connection Ready to Scan Model Name: bizhub C654 Low Paper

Maintenance System Settings Security **User Auth/Account Track** Network Box

Print Setting Store Address Fax Settings Wizard Customize To Main Menu

General Settings

User Authentication: ON (MFP)

Overwrite User Info: Restrict

Default Authentication Method: ON (External Server)

Public User Access: ON (Without Login)

Ticket Hold Time Setting (Active Directory): 600 Minutes (1-600)

Account Track: OFF

Account Track Input Method: Account Name & Password

Synchronize User Authentication & Account Track: Synchronize

Number of Counters Assigned for Users: (1-999)

When Number of Jobs Reach Maximum: Skip Job

Print Setting Store Address Fax Settings Wizard Customize To Main Menu

General Settings

User Authentication Setting

User Registration

Default Function Permission

Public User

Administrative Setting

Account Track Settings

Prohibited Function Login Setting

Print without Authentication

Simple Print Authentication Setting

External Server Settings

Public User Box Setting

User/Account Common Setting

Scan to Home Settings

Scan to Authorized Folder Settings

Counter Remote Control

Public User

Function Permission

Copy: Black Only

Scan: Full Color/Black

Save to External Memory: Restrict

External Memory Document Scan: Restrict

Fax: Full Color/Black

Print: Black Only

User Box: Allow

Print Scan/Fax TX: Full Color/Black

Manual Destination Input: Allow

Mobile/PDA: Allow

Limiting Access to Destinations

Reference Allowed Group

Search from List

Registered Reference Group Number

Total0

Access Allowed Level

0

KONICA MINOLTA Administrator Logout

PAGE SCOPE Web Connection Ready to Scan Model Name: bizhub C654 Low Paper

Maintenance System Settings Security **User Auth/Account Track** Network Box

Print Setting Store Address Fax Settings Wizard Customize To Main Menu

General Settings

User/Account Common Setting


Single Color > 2 Color Output Management: Color

Logout Confirmation Display Setting: OFF

User/Account Common Setting

Adding, Editing, & Deleting User Accounts from the Device Panel

1. Select the Menu button.
2. On the screen select Utility.
3. Select Administrator Settings. Enter the device admin password. Press OK.
4. Select the 4th option, User Authentication / Account Track.
5. If you have User Authentication turned on select the 2nd option: User Authentication Settings. If Account Track is turned on select the 3rd option: Account Track Settings.
6. If using User Authentication select User Registration. If using Account Track select Account Track Registration.
7. Select a free space to register the account and press the Edit button.
8. Enter the name of the account and the password to be used (password must be entered twice). To ensure greatest ease of use, it is recommended you keep passwords numeric so users can use just the keypad at the device to enter their passwords to log on.
9. Setting a **Maximum Allowance** will limit the number of copies and prints that can be made on that account. When an account reaches its limit the user can no longer print or copy until the limit is raised or the counter is reset. The default setting is no limit.
10. If you have a colour device selecting **Output Permission** will allow you to block colour all together on that account. Default setting allows colour output.
11. Press OK when finished entering account name, password, and if desired, maximum allowance and output permission.




To edit an account: follow steps 1-6 above and make the desired changes.

To delete an account: follow steps 1-5 above, select the account to be deleted, and press the Delete button at the bottom of the screen. Confirm when prompted.

Adding, Editing, or Deleting User Accounts Using the Web Connection

1. Type in the IP address of your device into the address bar of your web browser.
2. Select Administrator and click Login.
3. Enter the admin password (see your administrator for the device's admin password).
4. Click on User Auth / Account Track.
5. Click Account Track Settings. (If using User Authentication click on User Registration).
6. Click New Registration.
7. Leave Use Opening Number option selected, then enter the password twice.
8. Enter the name of the account.
9. Select whether or not to block colour output if registering the account on a colour device. Note: Output Permission (TX) refers to scanning and faxing. The colour permission for this function should be left on Allow.
10. Select a maximum allowance on the account if desired. If no limit is required then leave the Total Allowance option unchecked.
11. Click OK at the bottom of the screen.
12. Click New Registration to add the next account.
13. When finished adding new accounts click Logout at the top of the screen, then OK, to release the machine from Admin Mode (which locks out all users.).




To Edit an existing account click on the Edit button next to that account. You can change the password on the account, change restrictions on colour output, and change the limits (if any) on colour or black & white printing/copying.

To Delete an account click the Delete button next to that account and confirm when prompted.

Entering Account Codes into Print Drivers (PC's)

1. Click on the Windows Start button.
2. Click on Printers and Faxes (or in Windows 7: Devices and Printers).
3. Right click on the icon for the Konica Minolta printer.
4. Click on Printing Preferences.
5. Click on the Basic Tab.
6. Click on Authentication/Account Track.
7. If using **Account Tracking** with Password Only authentication then you only enter the password. Leave the Account field blank. Click OK, then click Apply to save your settings.


If using **User Authentication** change the option from Public User to Recipient User and enter the User Name and Password. Click OK, then click Apply to save the settings.



Pop Up Authentication (PC's)

- If printing from a general use computer where multiple users use different codes, then do not enter a code in the driver (as above). You can use Pop Up Authentication that prompts users to enter their codes every time they click Print.



1. Repeat steps 1-3 above.
2. Click on Properties (or if using Windows 7: Printer Properties)
3. Click on the Settings tab.
4. Click on Authentication Settings.
5. Click the checkbox for Pop up Authentication Dialogue when Printing. Click OK to close the pop up.
6. Click Apply to save all your settings, then OK to close the screen.



NOTE: If this option is grayed out you do not have permission to select the Pop Up option. Contact your network administrator to select the option for you. 11

Entering Account Codes into Print Drivers (MACs)

1. Open any file in any program and click File, Print.
2. Choose the Konica Minolta printer from the drop down menu.
3. Click on Output Method from the list of options.
4. Click on either Account Track or User Authentication, depending on which feature you are using.
5. When the Popup appears enter your password only if using Account Track with Password Only Authentication, or your User Name and Password if using User Authentication.
6. Click Save Setting, then click OK.




Pop Up Authentication (MAC's)

If printing from a general use computer where multiple users use different codes, then do not enter a code in the driver. You can use Pop Up Authentication that prompts users to enter their codes every time they click Print.


To turn on Pop Up Authentication:

1. Repeat steps 1-3 above.
2. Click on Detail Settings.
3. Highlight Administrator Settings, then click Settings...
4. Turn on the Pop up feature for the tracking method you are using. Click OK twice.



Generating Reports for Account Tracking & User Authentication — From the Device Display

1. Select the Menu button.
2. On the screen select Utility.
3. Select option #3, Administrator Settings. (See your administrator for the device's admin password).
4. Select option #4, User Authentication/Account Track.
5. Select option #5, Print Counter List.
6. Select the paper size you would like to print the report on.



1. Press Start.
2. The device will now generate a report and will not let you cancel out of that screen until the entire report is printed.

Counter List

P 1
06/04/2012 17:32
Serial No.
TC: 5079

Sample Report:

Copy and Print counters are added together in the Total Counter on the left side (dark yellow highlight).


Account Track Counter		Counter List													
No.	Account Name	Function Permission				Max. Allow- ance Sec	Maximum Color Allowance	Color	Black	Max. No. of Use Boxes	Maximum Number of User Boxes				
1	Test Account 1	Copy	Scan	Fax	Print	Print/Scan/ Fax/Fx	0	0	0	0					
		Full Color/Black	Full Color/Black	Full Color/Black	Full Color/Black	Full Color/Black									
		Custom Function Pattern Selection		Scan/Fax											
		Disable		Disable											
		Total Counter				Total Copy Counter				Total Print Counter					
		Total	Black	Full Color	2 Color	Single	Total	Black	Full Color	2 Color	Total	Black	Full Color	2 Color	
Total Large Size		40	0	40	0	0	0	0	0	0	40	0	40	0	
		20	0	20	0	0	0	0	0	0	20	0	20	0	
		Fax/Scan Counter		Fax Counter		Originals Counter		Paper Counter		Total Duplex Counter		Print Counter		Pause	
Total Large Size		0	0	0	0	0	20	20	0	0	20	0	20	Continue Job	
2	Test Account 2	Copy	Scan	Fax	Print	Print/Scan/ Fax/Fx	0	0	0	0					
		Black Only	Full Color/Black	Full Color/Black	Black Only	Full Color/Black									
		Custom Function Pattern Selection		Scan/Fax											
		Disable		Disable											
		Total Counter				Total Copy Counter				Total Print Counter					
		Total	Black	Full Color	2 Color	Single	Total	Black	Full Color	2 Color	Total	Black	Full Color	2 Color	
Total Large Size		116	116	0	0	0	0	0	0	0	116	116	0	0	
		58	58	0	0	0	0	0	0	0	58	58	0	0	
		Fax/Scan Counter		Fax Counter		Originals Counter		Paper Counter		Total Duplex Counter		Print Counter		Pause	
Total Large Size		0	0	0	0	0	58	58	0	0	58	0	58	Continue Job	
3	Test Account 3	Copy	Scan	Fax	Print	Print/Scan/ Fax/Fx	0	500	1000	0					
		Full Color/Black	Full Color/Black	Full Color/Black	Full Color/Black	Full Color/Black									
		Custom Function Pattern Selection		Scan/Fax											
		Disable		Disable											
		Total Counter				Total Copy Counter				Total Print Counter					
		Total	Black	Full Color	2 Color	Single	Total	Black	Full Color	2 Color	Total	Black	Full Color	2 Color	
Total Large Size		40	0	40	0	0	0	0	0	0	40	0	40	0	
		0	0	0	0	0	0	0	0	0	0	0	0	0	
		Fax/Scan Counter		Fax Counter		Originals Counter		Paper Counter		Total Duplex Counter		Print Counter		Pause	
Total Large Size		0	0	0	0	0	40	40	0	0	40	0	40	Continue Job	

Generating Reports for Account Tracking & User Authentication — From the Web Connection

1. Type in the IP address of your device into the address bar of your web browser.
2. Select Administrator and click Login.
3. Enter the admin password (see your administrator for the device's admin password).



4. From the colour coded menu on the left side choose Import/Export
5. Choose Counter and click on Export.
6. Choose Account Track Counter and click OK.



7. When prompted click Download.
8. Choose Save File and select a location on your computer to save the file. It will save as a Tab Text file.
9. When saving is complete click on Back to go back to the main screen.



10. Click Logout at the top of the screen to release the device from Administrator mode (which locks out all users)

11. Import the Tab Text file into Excel to make it easy to read. (Do not change any of the default import settings Excel chooses. Simply click Next or Finish when prompted).

Resetting Counters For Account Tracking on Konica Minolta bizhub Devices

This function can only be done using the PageScope Data Administrator utility, an installable program, or from the display panel of the device. It cannot be done from the Web Connection.

Resetting **All Accounts** to Zero from the Display Panel:

1. Select the Menu button.
2. On the screen select Utility.
3. Select Administrator Settings.
(See your administrator for the device's admin password)
4. Select option #4, Account Track/ User Authentication.
5. Select the third option Account Track Settings (or the second option, User Authentication Settings if using that feature).
6. Select the second option, Account Track Counter (or User Counter if using User Authentication).
7. Select the Reset All Counters button at the bottom of the screen. Confirm when prompted.



Resetting **A Single, Specific** Account to Zero from the Display

Panel: See steps 1-5 above.

6. Select the individual account on the screen and click Counter Details.
7. Select the Reset Counter button in the top corner of the page.
8. Press OK. Confirm you wish to reset the counter.